



MISS NIGHTINGALE INSTALLATION GUIDELINES

Dear Customer,

We appreciate your confidence in us with your purchase of Miss Nightingale!

We are convinced that you will enjoy our product a lot. To maximise the benefits of Miss Nightingale we strongly recommend you to read to the User Manual carefully.

Please focus specifically on the connection between the candle and the base.

There is only one way to connect candle and base. The pins of the candle have to match the right holes in the base. In order to do it correctly please follow the steps as described below carefully.

- Put the base horizontally on a flat surface
- Put the candle onto the base by connecting the pin with the red dot in the hole with the red dot on the base.
- Then twist the candle 90 degrees to the right until it locks, and the candle can not twist any further. The candle is than fixed correctly to the base.
- If the pin and the hole with the red dots are not aligned and you will still want to twist the candle on to the base you will damage either the candle, the base or both.

Regular cleaning

- Use a soft cloth to clean Miss Nightingale on a regular base.
- Miss Nightingale cannot go outside below 10C degrees.

Do you have more questions please contact sales@missolarlight.com

Miss Solar Light,
Annet van Egmond